



Tool & Hoist Products

SALES AND ENGINEERING DATA


2200 SERIES POWER UNIT MODEL 7835-E

325 R.P.M.

LEVER THROTTLE

FORM: 2909-2

DATE: 8-9-93



□ TORQUE TO 9 - 12 FT LBS

○ TORQUE TO 28 IN. LBS

* INCLUDED WITH 36772 CYLINDER

† INCLUDES 35967 GREASE FITTING

● INCLUDES 35323 GREASE FITTING

For parts and service information, contact your local ARO distributor, or the Customer Service Dept. of the Ingersoll-Rand Distribution Center, White House, TN at PH: (615) 672-0321, FAX: (615) 672-0601.

ARO Tool & Hoist Products

Ingersoll-Rand Company

1725 U.S. No. 1 North • P.O. Box 8000 • Southern Pines, NC 28388-8000

©1993 THE ARO CORPORATION • PRINTED IN U.S.A.

INGERSOLL-RAND®

PROFESSIONAL TOOLS

OPERATING PRECAUTIONS

WARNING: Repeated prolonged operator exposure to vibrations which may be generated in the use of certain hand-held tools may produce Raynaud's phenomenon, commonly referred to as Whitefinger disease. The phenomenon produces numbness and burning sensations in the hand and may cause circulation and nerve damage as well as tissue necrosis. Repetitive users of hand-held tools who experience vibrations should closely monitor duration of use and their physical condition.

AIR AND LUBE REQUIREMENTS

Air pressure of 90 p.s.i.g. (6 bar) at the air inlet of the tool is required for maximum motor efficiency. If necessary, an air regulator should be installed to maintain this air pressure when the tool is in operation.

Filtered and oiled air will allow the tool to operate more efficiently and yield a longer life to operating parts and mechanisms. A line filter capable of filtering particles larger than 50 microns should be used with a line oiler.

Filter-Regulator-Lubricator (F-R-L) assembly model 128231-800 is recommended for use with this air tool. The capacity of this F-R-L is adequate to provide clean (40 micron) oiled

and regulated air for the tool.

Flush tool with a solution of three parts cleaning solvent and one part light oil after each 40 hours of operation. After flushing, apply a small amount of spindle oil in air inlet and run free for one minute to insure proper lubrication.

Recommended hose size – 5/16" (8 mm) nominal inside diameter.

Recommended lubricants: spindle oil 29665, 1 qt. (.9 liter) container for oiler and air inlet; grease 33153, 5 lb. (2.3 kg) can for gears and bearings, "O" ring lubricant 36460, 4 oz. (113 g) tube for lubrication and installation of "O" rings.

MAINTENANCE

Disconnect air supply from tool or shut off air supply line to tool and exhaust (drain) air line to tool of compressed air before performing service or maintenance to tool.

Air tools are made of precision parts and should be handled with reasonable care when servicing. Excessive pressure exerted by a holding device may cause distortion of a part. Apply pressure evenly when disassembling (or assembling) parts which have a press fit. When removing or installing bearings, apply pressure to the bearing race that will be press fit to the mating part; if this is not practiced, Brinelling of the bearing races will occur, making replacement necessary. It is important that the correct tools and fixtures are used when servicing this air tool.

Disassembly should be done on a clean work bench with a clean cloth spread to prevent the loss of small parts. After disassembly is completed, all parts should be thoroughly washed in a clean solvent, blown dry with air and inspected for wear levels, abuse and

contamination.

Double sealed or shielded bearings should never be placed in solvent unless a good method of relubricating the bearing is available. Open bearings may be washed but should not be allowed to spin while being blown dry. When replacement parts are necessary, consult drawing containing the part for identification.

Before reassembling, lubricate parts where required. Use 33153 grease, or equivalent, in bearings. Use 36460 lubricant for "O" ring assembly. When assembling "O" rings, care must be exercised to prevent damage to the rubber sealing surfaces. A small amount of grease will usually hold steel balls and other small parts in place while assembling.

When ordering parts, be sure to list **part number, part name, model number and serial number of tool.** Use only genuine ARO® replacement parts

DISASSEMBLY AND ASSEMBLY OF TOOLS

DISASSEMBLY

DRIVE GEARING – Using wrenches on flats of ring gear and housing adapter, unthread and remove drive gearing assembly (37118) from tool. Tap drive end of ring gear with a soft face hammer; spindle and components will loosen from ring gear. NOTE: Do not disassemble further unless damage is evident. To disassemble, remove spacers (37127 and 37126). Alternately tap shafts to remove bearing.

AUXILIARY GEARING – Remove drive gearing. Loosen lock nut (35831) and unthread and remove gearing assembly (40826) from tool. Tap splined end of spindle with a soft face hammer; spindle and components will loosen from housing adapter. Remove bearing (33704) from splined end of spindle. Rotate snap ring, allowing removal of shafts and gears. Place shafts in spindle and alternately tap ends of shafts, loosening bearing (33704) from spindle.

MOTOR – The motor assembly may be removed from housing after the removal of gearing or head. Remove retaining nut (33694) and fastener (33700). Grasp cylinder in one hand and tap splined end of rotor with a soft face hammer; motor will come apart.

HEAD – Remove nut (36776), allowing removal of valve components.

ASSEMBLY

HEAD – Grease and assemble "O" ring (Y325-7) to valve stem (36777). Assemble valve stem, spring (32858), regulator (36775) and seal (36781) into valve

opening and secure with nut (36776).

MOTOR – Assemble bearing (33709) to end plate (33710), pressing on outer race of bearing. NOTE: Assemble with bearing markings facing out. Assemble spacer (33701) and end plate (33710) to rotor, pressing on inner race of bearing. Secure with sems fastener (33700), tightening to 28 in lbs. Coat blades with 29665 spindle oil and assemble to rotor slots – straight side out. Coat i.d. of cylinder (36772) with 29665 spindle oil and assemble to end plate (33710), aligning roll pin (Y178-22) with hole in end plate and air inlets of cylinder and end plate. Assemble bearing (33705) to end plate (33712), pressing on outer race of bearing. Assemble end plate to cylinder, pressing on inner race of bearing. Assemble retaining nut (33694) to end plate and torque to 9 – 12 ft lbs. Be sure rotor does not bind and assemble to housing. Assemble spacers (33699 and 33711) to housing.

AUXILIARY GEARING – Pack bearings and lubricate gears liberally with ARO 33153 grease when assembling. Assemble gears (46416) and shafts (40841) to spindle, aligning notch in shafts with snap ring (40843). Rotate open portion of snap ring 90° from shafts, securing shafts in place. Assemble bearings (33704) to spindle. Assemble retaining ring (33708) and spindle to housing adapter (35270). Assemble housing adapter to tool and secure with lock nut (35831).

DRIVE GEARING – Pack bearings and lubricate gears liberally with ARO 33153 grease when assembling. Assemble gears (46416) and shafts (37124) to spindle, aligning notch in shafts with spacer (37126). Assemble spacer (37128) and bearing (33704) to spindle. Assemble spacer (37127) to spindle and assemble spindle to ring gear. Assemble ring gear to tool.